



Wi-Fi Modem Self-Connect Guide

CODA-4582



WESTMAN | COMMUNICATIONS GROUP

Wi-Fi Modem Self-Connect Guide

What's in the box.



Modem
(Hitron CODA-4582)

↑
Install upright



Coax Cable



Power Cord



Ethernet
Cord

Let's get connected.

Follow these instructions for your first-time boot up or your factory reset of the CODA-4582.

Hitron CODA-4582: The modem will not be able to access the Internet without completing **Easy Connect** for the first time upon boot up or factory default resets.

- 1) If you have a device wired directly to the modem you can complete **Easy Connect** without connecting to Wi-Fi first.

Welcome to Hitron Easy Connect

We can have you connected to your Hitron Wi-Fi modem and online in just a few minutes.

We're going to:




LET'S GO



2) Connect to the Internet and choose a network name and password with **Easy Connect**.

- Using a Smartphone, Tablet, or Computer; check the settings or connection menu to ensure Wi-Fi is turned on.
- In the list of available networks, choose the Easy Connect Wi-Fi Network that includes the last digits of the serial number labelled on the back of the modem.
- After selecting the network, you will be prompted to enter your default key which is located on the back of the modem. (See image below)



- The modem will go through the steps required to check your network settings.
- 3) Once you are connected, open a web browser and follow the on-screen Easy Connect instructions to test your connection and customize your Wi-Fi settings
- 4) Select **Let's Go** and you will be ready to set up your new Wi-Fi network name and password.
- The network name entered here is what people will see when they want to discover and connect to your network.
 - Your password must be a **minimum of 8 characters long**, you should choose a password that no one will easily guess.
 - After re-entering the password and selecting **Confirm Setup** you will have an opportunity to double check your settings before selecting **Complete My Setup**.
- 5) Once you have configured your network and are online you will need to update the settings on your Wi-Fi devices with the new network name and password that you've configured, so that they are connected to the new network and modem.

Note: If you need assistance, please contact our support team at 204-717-2802.

Need More Assistance?

We're here to help.



support.westmancom.com

Search for "Self-Connect".

FOR TECHNICAL ASSISTANCE, PLEASE CALL
204.717.2802 or toll free **1.800.665.3337**



WESTMAN | COMMUNICATIONS GROUP

204.725.4300 1.800.665.3337 westmancom.com